
## ADJUST ANGULAR POSITION BY CLAMPING AT BALANCE ADJUSTER AND LOWER LOCK NUTS



SINGLE SPAN WIRE SIGN MOUNT - TYPE A